



**CR 826 - WM. H. SMIRS DRAINAGE WORK
FROM UNDER ROAD CULVERTS, DIG A 1-FOOT DEEP, 8 TO 10-FEET WIDE DRAINAGE DITCH**