



## PROVIDENCE POINT PHASE 2



Providence Point phase 2 is located on CR 643 approximately 4.5 miles south of the city of Farmersville.



Map data © OpenStreetMap contributors, Microsoft, Facebook, Inc. and its affiliates, Esri Community Maps contributors, Map layer by Esri